

INSTALLATION INSTRUCTIONS FOR

REGAL WALL

- This product is ETL listed.
- This product is suitable for use in indoor dry locations only.
- This product can mount to either a 4" square electrical box with round plaster ring or an octagon electrical box.
- The halogen model can be dimmed with a standard incandescent dimmer, fluorescent model cannot be dimmed.

CAUTION-RISK OF FIRE

This product requires installation by a qualified electrician.
Before installing, be sure to read all instructions and
TURN THE POWER TO THE ELECTRICAL BOX OFF.

INSTALLATION

STEP 1

Using the screws and universal crossbar provided, attach crossbar to junction box.



STEP 2

Temporarily remove inside reflector to install fixture.




STEP 3

Run fixture wire through fixture and canopy, then attach the fixture wires to 120V supply wires using wire nuts provided.



STEP 4

Carefully push all the wires into the junction box and attach fixture to the crossbar.



STEP 5

For double ended bulb, carefully insert one end of bulb into white marked (neutral) end of socket first, then insert other end into black marked (hot) end of socket. For halogen models, make sure that you do not touch the bulb with bare hands, use oil-free tissue or gloves to handle bulb. Then snap on bulb shield.



STEP 6

Place reflector into fixture. Slide glass diffusers into grooves on top and bottom of fixture.



STEP 7

Slide metal faceplate onto fixture and tighten thumb nuts.

Edge
LIGHTING